

WARNING: XLR USERS.
Revision 1 of the APOX-IS1
swapped the sex of the XLR connectors
from standard convention
You can still use the proper connectors if you place the connectors
on the opposite side of the board.
Or use the solder cup version, and wire appropriately

